

## Seat belt Port Pad Sewing Instructions

Cut 3 6.5" x 6.5" squares

6" x 6" batting or polyfil

Use a ¼" seam allowance

**Step 1:** Right sides together, sew 2 squares and batting, leaving a 2" opening. Fold the third square in half lengthwise with right sides together. Stitch down the side and across the bottom, leaving an opening for turning.

**Step 3:** Sew the Velcro onto the ends of rectangle. One strip on either side.



**Step 4:** Lay the rectangle across the middle of the square—pin well. Sew two seams, 2" away from each side.

**Step 2: Turn both pieces right sides out. Be sure to get the corners square. Fold in the seam allowance, press and stitch.**

